## **Model 2401-EWA** Alpha, Beta, Gamma Count Ratemeter

# M

#### Features

- Self-Contained Survey Instrument
- End-Window GM Detector
- Audible & Visual Alarm
- Simple to Use
- Low Cost
- Rugged

#### Introduction

The Model 2401-EWA is a pocket size radiation detection meter with an end-window GM detector for measuring levels of radiation. The detector is conveniently packaged inside the instrument, with a protective screen. Audible and visual alarms indicate radiation levels in excess of the user-adjustable alarm set point. The metal case offers excellent protection against abuse. The overall size and integrated design facilitate ease of use.

#### **Specifications**

Part Number: 48-2997

**INDICATED USE:** alpha, beta, gamma survey DETECTOR: 1.4 cm (0.57 in.) diameter end-window GM RANGE: 0-200 mR/hr; 0-210,000 cpm SENSITIVITY: typically 1050 cpm/mR/hr (<sup>137</sup>Cs gamma) **ENERGY RESPONSE:** energy dependent RESPONSE TIME: typically 11 seconds from 10% to 90% of final reading METER DIAL: 0–2 mR/hr; 0–2100 cpm, BAT OK MULTIPLIERS: x1, x10, and x100 AUDIO: click-per-event, may be turned off by moving selector to QUIET position **POWER:** 9 volt battery BATTERY LIFE: typically 250 hours with alkaline battery at normal background levels **CONSTRUCTION:** drawn and cast aluminum, with membrane panel **SIZE:** 4.6 x 8.4 x 13.5 cm (1.8 x 3.3 x 5.3 in.) (H x W x L) WEIGHT: 0.4 kg (0.9 lb), including battery ALARM: user-adjustable from 0 to full scale meter deflection, detected radiation over alarm setpoint triggers a red Alarm LED and steady audible tone whether in NORMAL or QUIET mode

### Options

Belt Clip (Model L-4397-176), metal clip Handle (Model L-4397-165-01), convenient L-shaped handle Case (Model L-2310517), zippered nylon case with web belt loop Case (Model L-231119), rugged water, dust, & crush resistant case Wrist Strap (Model L-4397-182), woven nylon lanyard with clip Model 2401-EW: same as Model 2401- EWA, but without audible & visual alarm



Ludium Measurements, Inc. P.O. Box 810, Sweetwater, Texas 79556 Web: http://www.ludiums.com Tel: 800-622-0828 / 325-235-5494 / Fax: 325-235-4672 / Email: sales@ludiums.com Note: specifications subject to change without notification. We are not responsible for errors or omissions.