Model 5 Gamma Survey Meter

Features

- 0–20 mSv/h (0–2000 mR/hr) Range
- Two Internal Energy-Compensated GM
 Detectors
- Rugged Construction
- 5-Range Analog Ratemeter



Introduction

The Model 5 is a gamma exposure ratemeter equipped with two internally housed, energy-compensated GM detectors that measure over the range of 0–20 mSv/h (0– 2000 mR/hr). The aluminum cast instrument housing with its separate battery compartment and accompanying metal handle offer an industrial robustness and quality that promote long lasting protection and instrument life. The front-panel controls include a rotary switch for selecting the five display ranges and instrument shut-off, an audio on/off switch, a fast/slow response switch, and pushbuttons for count reset and battery test. The Model 5 is a complete turn-key system and includes two "D" cell batteries.

Options

Check Source: Model L-01-5196 Lighted Handle: Model L-4464-154 Shoulder Strap: Model L-4363-413 Portable Scaler Option: Model L-4464-114



Specifications Part Number: 48-1607

INDICATED USE: gamma survey **DETECTOR**: 2 energy-compensated GMs, housed inside instrument enclosure **ENERGY RESPONSE:** within 15% of true value from 60 keV to 3 MeV **RANGE**: 0-20 mSv/h (0-2000 mR/hr) HIGH VOLTAGE: 540 +/- 25 Vdc WORKING ENVIRONMENT: normal working conditions METER: analog dial: 0-2 mR/hr, BAT TEST (others available) MULTIPLIER: x0.1, x1, x10, x100, x1000 BACKLIGHT: no **OVERLOAD PROTECTION: yes** AUDIO: built-in unimorph type speaker with ON/ OFF switch ALERT/ALARM: no **RESET**: pushbutton to zero meter **CALIBRATION CONTROLS**: accessible from the front of the instrument RS-232 PORT: no POWER: two each "D" cell batteries (housed in sealed compartment that is externally accessible) **BATTERY LIFE**: typically greater than 2000 hours TEMPERATURE RANGE: -20 to 50 °C (-4 to 122 °F) **SIZE**: 19.0 x 8.9 x 21.6 cm (7.5 x 3.5 x 8.5 in.) $(H \times W \times L)$ **WEIGHT**: 1.6 kg (3.5 lb), including batteries

Ludium Measurements, Inc. P.O. Box 810, Sweetwater, Texas 79556 Web: http://www.ludiums.com Tel: 800-622-0828 / 325-235-5494 / Fax: 325-235-4672 / Email: sales@ludiums.com Note: specifications subject to change without notification. We are not responsible for errors or omissions.