

**LUDLUM MEASUREMENTS, INC.**

501 OAK STREET  
P.O. BOX 810  
SWEETWATER, TEXAS 79556  
WEBSITE: [www.ludlums.com](http://www.ludlums.com)



**DESIGNER AND  
MANUFACTURER  
OF**

*Scientific and Industrial  
Instruments*

**800-622-0828(US & CANADA) 325-235-4672(FAX) 325-235-5494 email:[bhuckabee@ludlums.com](mailto:bhuckabee@ludlums.com)**

Instructions for a Nuclear Power Plant and/or Specifically Licensed Nuclear Service Providers to send instrument(s) with fixed radioactive contamination to Ludlum Measurements Inc.

1. The shipment from the NPP containing fixed contaminated instruments must be clearly indicated on the Fixed Contaminated Instrument (FCI) Return Goods Form.
2. The FCI Return Goods Form shall contain an itemized listing of contents and state the level of fixed contamination on each item and if possible, the approximate location the contamination is located.
3. The maximum level of fixed contamination shall not exceed 200 nCi total activity per item and/or the dose rate at shall not exceed 1 mR/hr at 1 cm.
4. **The allowable removable contamination limits for our facility are none or zero.** Any removable contamination detected and the shipment shall be returned to the customer, along with any item that became contaminated due to the deposition of removable contamination i.e. gloves, leak test swabs, etc.
4. The outside of the box shall be marked in letters visible, legible and a minimum of 25 mm in height on 2 sides the letters "FCI".
5. The shipment shall be addressed; Ludlum Measurements Inc, Attn:FCI Dept, 503 Oak St, Sweetwater, TX 79556.
6. Packages that contain contaminated instruments not following the above will be returned to the consignor unrepaired/uncalibrated at the customer's expense.

Note: Ludlum Measurements' Radioactive Materials License allows us to accept fixed contaminated goods from Nuclear Power Plant customers and/or Specifically Licensed Nuclear Service Providers ONLY.

Bill Huckabee  
Radiation Safety Officer

Form RS 27 08 Dec 2015

● **Serving The Nuclear Industry Since 1962** ●

# LUDLUM MEASUREMENTS, INC.



503 OAK STREET, SWEETWATER, TEXAS 79556  
ATTN: FCI DEPARTMENT  
800.622.0828 325.235.5494 fax: 325.235.4672  
www.ludlums.com



## ▼ FIXED CONTAMINATION INSTRUMENT RETURN FORM ▼

Company Name: \_\_\_\_\_

Contact Person: \_\_\_\_\_ Phone: (     ) \_\_\_\_\_  
(End-User)

Bill to Address:  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Ship to Address:  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Ship Via: UPS FedEx Other \_\_\_\_\_

Instrument / Probe Model Number	Serial Number	Approx Activity nCi	Isotope(s)	Location of Contamination

Purchase Order # \_\_\_\_\_

Call for PO#  Call with Est.  Call for CC#

Credit Card # \_\_\_\_\_ - \_\_\_\_\_ - \_\_\_\_\_ - \_\_\_\_\_

Expiration: \_\_\_\_/\_\_\_\_

Contact Person: \_\_\_\_\_  
(Purchasing)

Phone: (     ) \_\_\_\_\_

E-mail: \_\_\_\_\_

Special Shipping Instructions or Other Special Instructions: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_