Model 43-143-1 100 cm² Gas Flow Proportional Detector



Specifications

Part Number: 47-4011

EQUIVALENT TO EBERLINE HP-100 INDICATED USE: alpha beta survey SUGGESTED INSTRUMENTS: Models 12, 16, 18, 2000, 2200, 2221, 2224-1, 2241-2, 2350-1, 2360, 4906-Series **DETECTOR TYPE**: gas proportional RECOMMENDED COUNTING GAS: P-10 (10% methane, 90% argon) is recommended. Other counting gases are also acceptable. GAS FLOW: counting gas enters through the inlet port (located at the bottom side of the detector) and then exhausts through a small pin-sized hole located at the top of the detector to ensure good gas flow across the volume. The gas flow rate is approximately 30–50 cc/min. DETECTOR CONNECTOR: MHV EFFICIENCY (4π): 20% for 239Pu; 15% for 14C; 30% for 99Tc; 20% for 90Sr/90Y less than 1% for gamma SIMULTANEOUS ALPHA/BETA COUNTING: 17.5% for ²³⁹Pu; 20% for ⁹⁹Tc; 20% for ⁹⁰Sr/⁹⁰Y WINDOW: typically two layers of metalized polyester (0.8 mg/cm², other thicknesses available), easy access for replacement by simply sliding the removable front cover off the detector body WINDOW AREA: 100 cm² (15.5 in²) active, 70 cm² (10.9 in²) open BACKGROUND: alpha: 3 cpm or less when operating at alpha-only plateau region beta-gamma: typically 350 cpm or less in a 10 µR/hr field OPERATING VOLTAGE: alpha typically 1100-1400 volts; beta-gamma: typically 1600-1800 volts COUNTER THRESHOLD SETTING: typically 2-5 mV for scaler or gross counting instrument **SIZE**: 8.4 x 11.9 x 15.5 cm (3.3 x 4.7 x 6.1 in.) (H x W x L), with handle

WEIGHT: 0.59 kg (1.3 lb)

Detector Accessories

Part Number	Quantity	Description
2310017 1	2-stage regulator	
22-9522 2	fittings for flowmeter (1/8 in. MPT to 1/4 in. tubing)	
21-9547 1	10 to 100 cc flowmeter (1/8 in. MPT to 1/4 in. tubing)	
22-9514 AR	x feet 1/4 in. OD vinyl tubing for gas supply	

Ludium Measurements, Inc. P.O. Box 810, Sweetwater, Texas 79556

Web: http://www.ludlums.com Tel: 800-622-0828 / 325-235-5494 / Fax: 325-235-4672 / Email: sales@ludlums.com Note: specifications subject to change without notification. We are not responsible for errors or omissions.

Sept 2016