

**LUDLUM MODEL 6
GEIGER COUNTER**

**February 2011
Serial No. 170123 and Succeeding
Serial Numbers**

**LUDLUM MODEL 6
GEIGER COUNTER**

**February 2011
Serial No. 170123 and Succeeding
Serial Numbers**



LUDLUM MEASUREMENTS, INC
501 OAK STREET, P.O. BOX 810
SWEETWATER, TEXAS 79556
325-235-5494, FAX: 325-235-4672

STATEMENT OF WARRANTY

Ludlum Measurements, Inc. warrants the products covered in this manual to be free of defects due to workmanship, material, and design for a period of twelve months from the date of delivery. The calibration of a product is warranted to be within its specified accuracy limits at the time of shipment. In the event of instrument failure, notify Ludlum Measurements to determine if repair, recalibration, or replacement is required.

This warranty excludes the replacement of photomultiplier tubes, G-M and proportional tubes, and scintillation crystals which are broken due to excessive physical abuse or used for purposes other than intended.

There are no warranties, express or implied, including without limitation any implied warranty of merchantability or fitness, which extend beyond the description of the face there of. If the product does not perform as warranted herein, purchaser's sole remedy shall be repair or replacement, at the option of Ludlum Measurements. In no event will Ludlum Measurements be liable for damages, lost revenue, lost wages, or any other incidental or consequential damages, arising from the purchase, use, or inability to use product.

RETURN OF GOODS TO MANUFACTURER

If equipment needs to be returned to Ludlum Measurements, Inc. for repair or calibration, please send to the address below. All shipments should include documentation containing return shipping address, customer name, telephone number, description of service requested, and all other necessary information. Your cooperation will expedite the return of your equipment.


**LUDLUM MEASUREMENTS, INC.
ATTN: REPAIR DEPARTMENT
501 OAK STREET
SWEETWATER, TX 79556**

**800-622-0828 325-235-5494
FAX 325-235-4672**

TABLE OF CONTENTS

1. GENERAL.....	1
2. SPECIFICATIONS	1
3. DESCRIPTION OF CONTROLS AND FUNCTIONS	1
4. OPERATING PROCEDURES.....	2
5. CALIBRATION	2
6. MAINTENANCE	2
PARTS LIST	4
Model 6 Geiger Counter.....	4
Circuit Board, Drawing 363 X 452.....	4
Wiring Diagram, Drawing 363 x 466	5
DRAWINGS AND DIAGRAMS	6

REV #	ALTERATIONS	DATE	BY
1	VALID	11/27/89	BK
2	UPDATED FRONT PANEL	4/22/06	CMC



DWN DATE	CMC 4-22-06	CHK DATE		APP DATE	4-24-06
PART NUM	4363-262	SCALE	FULL	OTHER	
TITLE M 6 GEIGER COUNTER					
LUDLUM MEASUREMENTS, INC. 501 CHIK STREET SWEETWATER, TEXAS 75086		SERIES	363	SHEET	262

Model 6 Geiger Counter

February 2011

1. GENERAL

The Model 6 is a portable battery operated Geiger Counter with an internal GM detector. The instrument features a regulated high-voltage supply, five-position switch for selecting battery check or scale multipliers of X1, X10, X100, and internal calibration controls for the range

multipliers, and high voltage. The meter scale reads 0 to 10 mR/hr, producing a range of 0 to 1 R/hr with the three linear range multipliers. The unit body is made of cast aluminum, including the meter housing. The instrument cover (can) is 0.23 cm (0.090 in.) thick aluminum.

2. SPECIFICATIONS

POWER: two standard "D" size batteries

LINEAR RANGES: 0-1 R/hr; meter presentation of 0-10 mR/hr with range multiples of X1, X10, and X100

DETECTED RADIATION: gamma; X-ray

LINEARITY: $\pm 10\%$ full scale

BATTERY LIFE: exceeds 600 hours with a fresh set of alkaline "D" cell batteries

BATTERY DEPENDANCE: instrument calibration changes less than 3% within battery check limits on meter

OVERLOAD PROTECTION: overload circuitry deflects meter pointer to full scale when the detector is exposed to radiation intensities greater than the upper operating limit (greater than 10 R/hr)

METER: 1 milli-amp, 6.4 cm (2.5 in.) scale with pivot-and-jewel movement

RESPONSE TIME: four seconds measured from 10% to 90% of full scale

DETECTOR: internally-mounted 71412 tube

SIZE: 10.7 x 8.9 x 21.6 cm (4.2 x 3.5 x 8.5 in.) (H x W x L), less handle

WEIGHT: 1.4 kg (3 lb) less detector, batteries, and handle

FINISH: drawn-and-cast aluminum, with beige powder coat

3. DESCRIPTION OF CONTROLS AND FUNCTIONS

Range Multiplier Selector Switch: A five-position switch marked OFF, BAT, X100, X10, and X1. Turning the range selector switch from OFF to BAT position provides the operator a battery check of the instrument. A BAT check scale on the meter provides a visual means of checking the battery status. Moving the range selector switch to one of the range multiplier positions (X1, X10, X100) provides the operator

with an overall range of 0-1R/hr. Multiplying the scale reading by the multiplier determines the actual reading.

Range Calibration Adjustments: Internal potentiometers which allow individual calibration for each range multiplier. Removing the instrument housing will allow access to these controls.

Model 6 Geiger Counter

February 2011

4. OPERATING PROCEDURES

Note: To open the battery lid, twist the lid button counter-clockwise a quarter of a turn. To close, twist clockwise a quarter of a turn.

- Open the battery lid and install two "D" size batteries. Note (+) (-) marks on the inside of the lid. Match the battery polarity to these marks.

Note: Center post of flashlight battery is positive.

- Close the battery box lid.

- Switch the range switch to BAT. The meter should deflect to the battery check portion of the meter scale. If the meter does not respond, recheck that the batteries have proper polarity.
- Turn the range switch to X1. Expose the instrument to a radiation check source. The meter should respond.
- Check calibration and proceed to use the instrument.

5. CALIBRATION

- For detector operating point, remove the instrument housing and adjust R33 (Drawing 363 x 452) for 550 volts.

Note: Measure high voltage with a Model 500 Pulser or a high-impedance voltmeter with a high-meg probe. If one of these instruments is not available, use a voltmeter with a minimum of 1000 megohm input resistance.

- Do not use a vacuum tube type voltmeter for this adjustment unless an external high-voltage multiplier probe is used.

- Switch the instrument range multiplier switch to X100 position. Place the detector on calibration range center line with the detector perpendicular to the radiation source. Expose the detector to a calibrated gamma radiation field, which corresponds to approximately 80% of full meter scale. Adjust the X100 range calibration control for the proper reading. Position the instrument in the field, which corresponds to approximately 20% of meter scale. Confirm meter indicates within 10% of reading. Repeat the calibration procedure for the X10 and X1 range positions.
- Replace the instrument housing.

6. MAINTENANCE

- Instrument maintenance consists of keeping the instrument clean and periodically checking the batteries and the calibration.
- An instrument operational check should be performed prior to each use by exposing the

detector to a known source and confirming the proper reading on each scale.

- Recalibration should be accomplished after any maintenance or adjustment of any kind has been performed on the instrument.

Model 6 Geiger Counter February 2011

Battery replacements are not considered to be maintenance and do not normally require the instrument to be recalibrated.

- Ludlum Measurements recommends recalibration at intervals no greater than one year. Check the appropriate regulatory agencies' regulations to determine required recalibration intervals.
- The batteries should be removed and the battery contacts cleaned of any corrosion at least every three months. If the instrument has been exposed to a very dusty or corrosive atmosphere, more frequent battery servicing should be used.
- Use a spanner wrench to unscrew the battery contact insulators, exposing the internal contacts and battery springs. Removing the handle will facilitate access to these contacts.



NOTE

NEVER STORE THE INSTRUMENT OVER 30 DAYS WITHOUT REMOVING BATTERIES. ALTHOUGH THIS INSTRUMENT WILL OPERATE AT VERY HIGH AMBIENT TEMPERATURES, BATTERY SEAL FAILURE CAN OCCUR AT TEMPERATURES AS LOW AS 37.8 °C (100 °F).

**Model 6 Geiger Counter
February 2011**

Ref. No.	Description	Part No.	Ref. No.	Description	Part No.
MISCELLANEOUS			MISCELLANEOUS		
P2	CONN-640456-9 MTA100	13-8094	M1	PORT BEZEL W/MOVEMENT	4363-188
			*	PORT BEZEL W/GLASS	4363-352
7 EA.	CLOVERLEAF 011-6809-000-599	18-8771	*	PORT METERFACE	7363-136
			*	METER MOVEMENT	15-8030
	Wiring Diagram, Drawing 363 x 466		*	PORTABLE KNOB	08-6613
			*	MAIN HARNESS Model 6	8363-622
	CONNECTORS		*	BATTERY CONTACT SET CASTING SCREENED	
J1	CONN-640442-9 MTA100	13-8169	*	Model 6	9363-324
			*	CAN ASSY. Model 6	4363-321
	SWITCHES		*	BATT LID W/LATCHSET Model 6	9363-325
S1	D3G0402N	08-6501	*	PORT HANDLE (ROLLED) W/SCREWS	7363-139
	BATTERY				
B1-B2	DURACELL "D"	21-9313			

**Model 6 Geiger Counter
February 2011**


DRAWINGS AND DIAGRAMS

Model 6 Front Panel, Drawing No. 363 x 262 (before page 1)

Main Circuit Board, Drawing No. 363 x 452

Main Circuit Board Layouts, Drawing No. 363 x 464


Wiring Diagram, Drawing No. 363 x 466



REV	AUTHORITY	ZONE	LIB	DESCRIPTION	DATE	APPROVED

REVISED CNO	09/01/95	LUDDUM MEASUREMENTS INC.
DR PWH	12/15/91	TITLE : MAIN BOARD
ISSN PH	12/15/91	BOARDN 5383-610
APPD <i>RDS</i>	<i>2/16/92</i>	SIZE MODEL
NEXT HIGHER ASSY.	C	B
15-749-380	27-000-03	56353510
SHEET	363	462
SHEET	OF	

EFF. AUTHORITY ZONE 1 IIR DESCRIPTION DATE APPROVED



UPDATED	01/28/92	LUDLOW MEASUREMENTS INC.	
BR. CDG		TITLE: WIRING DIAGRAM	
PERSON		BOARD	353-621
APPRO	<i>R. J. Felt</i>	SIZE	MODEL
		C	B
		NEXT HIGHER ASSY.	SERIES
			353
			SHEET
			466
			SHEET
			OF
			1